




## Add Your Custom Design to GamingPro- SOP



Read through the SOP carefully before the DIY process.

1. Unscrew the four screws on the front cover. Do not disassemble any other screw in order to keep your warranty.
2. Make sure your custom designed cover aligns the fan cover steadily, and then lock the four screws back to the original places.
3. (Optional) If you prefer not to expose the four screws, install the two decoration plates provided in the 3D file onto the front cover.

### Notes

- Palit provides two versions of 3D files.
- ✓ **Creator Version:** For 3D editing masters. The file offers a plain cover without any pre-design on it. Users can take it as basement to design their own cover.
- ✓ **Painting Version:** For general users. The file comes with pre-designed patterns. Users can simply paint the cover that fits their own style.
- Each version contains two file types. Choose the proper file depending on the dimensions your 3D printer can make.
- ✓ **Standard File:** The length is over 300mm.
- ✓ **Two Pieces File:** The length is under 200mm.
- ✓ There's no limitation for 3D printer whether FDM, SLA or others.